


Ettermonteringen - ASAM A7



Signal til påbygger kontakt X2

Anslusstecker X2	Funktion	
X2.52/4	Klemme 54 (Bremslys)	
X2.52/8	Klemme 58 (Baklys)	
X2.52/10	Blinklys Venstre	+24V DC OUT DURING LEFT TURN LIGHT SIGNAL ACTIVATED (to yellow wire ADP-36FV)
X2.52/11	Blinklys Høyre	+24V DC OUT DURING RIGHT TURN LIGHT SIGNAL ACTIVATED (to yellow wire ADP-36FV)
X2.52/51	Motorturtall eller V-Signal	
X2.52/52	Ryggelys	+24V DC OUT DURING REVERSE GEAR LIGHT ACTIVATED (to yellow wire ADP-36FV)